



HOW TO MEASURE AN ARCH WINDOW

HINT: Always measure the width first and then the height. Remember to measure every window, even when they appear to be the same size. Also use a metal tape measure - it won't stretch like a cloth tape and distort measurements. Recheck all measurements twice!!